Os 订

USER MANUAL

c· a_pv

MODEL: PM1O

01
02
03
04
05
06
07-10
10-11
11
12-13
14
15

To ensure your safety and to reduce the risk of electric shock, please take the time to read through this manual and become familiar with how to use your new hi-fi correctly. Please keep this manual safe for future reference.

Power
This hi-fi should only be used with standard mains supply at the voltage stated on the rear panel.

Ventilation
This unit emits heat. Never block the vents, or cover the unit when in use.

Location
Please locate your hi-fi in a cool place, away from direct heat sources such as radiators. Keep away from moisture and water.

No user serviceable parts
Don't open the casing. You risk electric shock. Please refer to a qualified technician for all repairs.

Cleaning
Unplug before cleaning! Don't use solvents as these will damage the appearance of your hi-fi.

Unplug when not in use
If you don't intend to use your hi-fi for a period of time, please unplug it from the mains supply.

Video Tray
Please ensure that the disk tray is free from obstruction. If it is blocked, it could damage the mechanism or your fingers!

Heavy Objects
Please don't place heavy objects on your hi-fi, or stand on it. It will break!

Linking to other sources
Before connecting to other devices, please make sure you turn the volume down, or switch the hi-fi off.

Radium laser
Your hi-fi contains a laser. Never take the unit apart and look into the laser – it will harm your sight.

Disc
Don't try and play disks that are damaged or distorted in any way. Doing so could damage your hi-fi and invalidate the warranty.

Maintenance & Repair
Your hi-fi has been designed to give you long and reliable service. There are no user-serviceable parts, and all repairs should be entrusted to a qualified technician.

Safety Inspection
Please check the power cable and plug at regular intervals and ensure that there is no damage to the insulation. If either becomes damaged, please disconnect from the mains supply, and have the cable replaced by a qualified technician.

Notes on handing

1. When transporting the hi-fi, the original shipping carton and packing materials are best. For maximum protection, repack the unit as it was originally packed at the factory.
2. If your hi-fi remains in contact with other objects or materials, it may become marked.
3. Avoid using solvents to clean your hi-fi, as these will damage the finish.
4. Remove discs when not in use, and unplug the hi-fi from the mains if you do not intend to use it for some time.

Siting near AV Units

If you locate your hi-fi very close to the TV, you may experience picture distortion. When this happens, just move it slightly away from the TV.

Notes on cleaning

1. Wipe with a soft cloth.
2. Deal with small stains by using a very slightly damp cloth after unplugging from the mains supply.
3. If you must use a proprietary cleaner, try it first on part of the hi-fi that isn't visible to make sure that it doesn't damage the casing.

Warning: Unplug the unit when cleaning with anything other than a dry cloth!

Notes on cleaning discs:

1. Do not touch the playback side of the disc.

2. Wipe the disc with a soft cloth from center outwards. If there are fingerprints or other marks, a slightly damp cloth may help. Don't use solvents or abrasive cleaners. Be careful not to scratch the disk as you wipe it.

3. Store your disks carefully, and keep them away from heat sources.
4. Don't try and play damaged or broken disks – you will damage the hi-fi and could invalidate the warranty.

Notes on batteries:

Batteries contain acid, and can leak. Leaking batteries will damage the remote control.

1. Observe polarity – don't insert the batteries the wrong way around.
2. Don't mix new and old batteries.
3. Avoid using different brands or types of battery.
4. Don`t leave damaged or exhausted batteries in the remote.
5. If you don't intend to use the remote for some time, remove the batteries.
6. If the remote becomes a bit sluggish, or you have to use it closer to the hi-fi, it's time to replace the batteries..
7. If the batteries leak, please clean the battery compartment well with a mild alkaline and dry it well.
8. Always dispose of old batteries correctly. Most supermarkets have a collection point for old batteries.

Notes on the remote control:

1. Please use the remote within 7m of your hi-fi.
2. Avoid subjecting the remote to excessive shock or vibration.
3. Don't get the remote wet or mix it with your beer or sauvignion blanc
4. Don`t dismantle the remote control.

You can use a Chromatism video cable to connect your Hi-Fi to the TV.

Or you can use a standard RCA cable to connect to TV's and other devices.

Red & White carry the left and right audio signal, while yellow caries the video signal.

Note: Be careful not to short circuit the speaker outputs, doing so can damage your hi-fi. Also, you shouldn't use with speakers other than the Osotto speakers supplied with the unit.

(8) (7) (2) (6) (1) (4) (5)

(1)

(2)

(3)

(4) (5)

(14) (13)

(9)

(16)(17) (11) (12) (3) (10)

(15)

1. Previous function key
2. Logo 3.USB input
4.Play/pause function key 5.Next function key 6.Product model
7.Display
8.Volume+/-function key 9.Power
10.Function function key 11.DVD door
12.Sd card function key 13.Source key 14.Search key
15.Tone function key 16.Earphone out 17.AUX output

1.Audio output
2.Y.Cb.Cr and progressive scan output
3.Video output 4.FM antenna jack

5. Wire clamp for speakers

5. 0405

1. Mute function keys 2.power function keys
3.digital number function keys 4.goto function keys
5.radio function keys 6.DVD/SD/USB function keys 7.play/pause function keys 8.return function keys
9.setup function keys 10.up function keys 11.Auto search 12.left function keys
13.down function keys 14.bass+ function keys 15.volume- function keys 16.bass- function keys 17.angle/del function keys 18.copy function keys 19.p/n function keys 20.repeat function keys 21.open/close function keys 22.previous function keys 23.next function keys
24.fast backward function keys 25.fast forward function keys 26.title function keys
27.menu function keys 28.stop function keys 29.zoom function keys 30.right function keys 31.treb+ function keys 32.volume- function keys 33.treb- function keys 34.subtitle function keys 35.audio function keys
36.slow function keys 37.dsp function keys 38.osd function keys 39.reset function keys 40.source function keys 41.v-mode function keys

SYSTEM SETUP:

Use the “Setup” option on the remote control to access the setup functions in your hi-fi.

The following instructions will guide you through the advanced setup features that you will want to navigate.

1. SYSTEM SETUP

TV SYSTEM
Get into ”TV SYSTEM” options first, press the ”RIGHT” key again, and select the settings that you want to change.

POWER RESUME:

This feature gives you a screen saver option.

VIDEO

Get into "VIDEO" options first, again press "RIGHT" key to get into the next class menu. From here, select the video output type:
1/ Select this option if you are using a Chromatism

type of cable.

2/ T V-RGB: Select this option when using standard connections.

3/ P-SCAN YPBPR: The Y,Cb, Cr output can be used, and you may need to use the scan on your TV to find the signal.
.
4/ PC- VGA Line can also be utilized as a video device, using this option

.

TV TYPE

Select the screen format in this sub-menu to get the optimal picture size based upon your TV or video device.

PASSWORD

You can set a PIN here. Choose any number between 0000 and 9999. Be sure to write it down and keep it safe!

3.AUDIO SETUP

Setting structure as follows:
AUDIO OUT

RATING

Certain DVD disks carry an age restriction and when the rating is selected, will prevent playback unless you enter your PIN number. Please note that this feature is not available on all DVD's.

DEFAULT
You can restore the standard factory settings using this option.

2. LANGUAGE SETUP

Setting structure as follows:

OSD LANGUAGE
Set the “On Screen Display” language using this option.

AUDIO LANG
Select your desired audio language from this option.

SUBTITLE LANGUAGE
You can select your desired subtitle language from here. Please note that the DVD must have subtitles included for this feature to work.

MENU LANGUAGE
You can select the menu language using this option.

4. VIDEO SETUP

Setting structure as follows: BRIGHTNESS
Adjust the output signal brightness

.

CONTRAST
Adjust the contrast of the picture from here.

HUE
Adjust the Hue from here.

SATURATION
Adjust the saturation of the colours in the picture from here.

5. SPEAKER SETUP
DOWNMIX
You can select different speaker settings to emulate surround sound or standard stereo from this option.

6. DIGITAL SETUP
Setting structure as follows:
OP MODE
You can select the operating mode from here.

DYNAMIC RANGE
You can control the dynamic range of the sound from here. This can be useful in small rooms.

DUAL MONO
Select stereo and mono options from here. Usually, you would leave the hi-fi in stereo mode.

The USB copy operation:

1. MP3 document copy:
During playback, press the “COPY” button on the remote.

2. MP4 copy:
Use the up and down keys to select the song that you to want to copy then press “COPY” on the remote control.

3. CD copy:
During playback, press the “COPY” button on the remote.

Ratio especially rate enactment
Move high and bright toŸBITRATEŸoptions, then pressŸENTERŸThe key carry on enactment, ratio especially the rate be big to copy of the document capacity correspond to become big.The system recognize tacitly for: 128KBPS

Establish ID3 an information
Move high and brigh toŸthe CREATE ID3 TAGŸ options,howeverEmpresspressŸENTERŸthe key carryon make selection or cancel.After making selection this,The meeting document will take an ID3 information when this time copy,
this ID3 letter Interest from the system auto is born

Establish document row form
Move high and bright toŸCREATE PLAYLISTŸ options,Then pressŸENTERŸthe key carry
on make selection or cancel.Make selection this When this time copy,auto a born document row form.

Copy the document make selection
Move high and bright toŸTRACKSŸ options, counteract a square rightwards The key get into, then pressŸENTERŸthe key carry on make selection or cancel.
Note:Want to insure the capacity in the U dish first enough origin time operation, and and want to put this machine of USB importation socket.If want to copy together system a meeting an overlay last time of document.In the process of copy in,
disallow to pull out U dish or shut down, otherwise result in to damage this machine. Such as copy behind detection not a reading book U dish, please carry on a format to turn with the computer, please keep before the format turn importan ce data.

Carry on copy
Move high and bright toŸSTARTŸ options, at this time the right side Now this time information contents for copy.Then press ŸENTERŸthe key fasten All write in a CD contents USB with the MP3 format. BE copy
to make Return an ability to appreciate in the meantime when the speed which use one multiple carried on copy Kao The contents of shell, the choice be 2 multiples, have no voice.
Note:At useŸENTERŸthe key cut over multiple of time, meeting have a little Pound at a voice, this phenomenon belong to normal phenomenon.

cancel copy
Be copying a status to move the high and bright toŸCANCELŸpicking,Then clickŸENTERŸthe key is then.

Withdraw to copy interface
Move the high and bright toŸQUITŸ picking, then click ŸENTERŸThe key is then.

RADIO

FM
According to the panel or the remote control ŸFMŸkey to enter the host in the acoustic, And the screen shows the current radio frequency, and Taiwan.
Note: FM this conversion is key,according to the ŸPlay / PauseŸ key will be transferred to DVD, according to ŸTVŸ will be key to enter the state of external sources.

TAIWAN MANUAL SEARCH
According to the panel or the remote control
/ FRE-ŸandŸ / FRE+Ÿbutton, a
manual search of Taiwan can move forward or backward you want to search for radio programs. SEARCH
According to the panel or the remote control
ŸSEARCHŸbuton, the machine automatically Taiwan found a wide band.
FM frequency range:87-108MHZ(each step 50KHz)
Note:The program received after the machine will automatically save the current Taiwan,and Taiwan closed with the effect of the radio signal strength of a great relationship,if the automatic search in the process of Taiwan to collect the
money or miscellaneous Taiwan,please use the manual Taiwan`s frequent selected search or seizure of Taiwan to adjust.

T/F
By remote control on theŸGOTOŸbutton, the screen appeared on the frequency of elections, And then use the number keys you want to enter the radio frequency.
FM frequency range:87-108MHZ
Note: The number of effective enough in front of the three, set up the first 0.

UP AND DOWN THERADIO

Or by remote control panelŸ /CH- Ÿand Ÿ / CH +Ÿbutton,you can select up and down the two have kept a good radio show.

Note: You can program favorite radio frequencies adjacent to the existence of Taiwan, location.

MONO/STEREO

By remote control on theŸSEARCHŸbutton, you can select mono And to stereo channels. Note: not enough signal strength to listen to the program, select the proposed MONO.

RADIO STORAGE

OperationŸAUTOŸ function, this will be followed by an opportunity to search The radio programs are automatically saved in order to position the station to operateŸ Manual setzed TaiwanŸ or ŸT / FŸ funtionn, the local At present, radio frequency automatic storage of the current number of Taiwan.

Tips: If the proposed resumption of Taiwan have the effect of noise or poor can not choose MONO improve ment can be adjusted in the acoustic antenna location, direction of the antenna put up the best reception quality.

Playing operation

SEQ PALY

1ŸAfter reading disc, the machine enters to broadcast automatically.

2ŸClick while stop the status ŸPLAY/PAUSEŸ.

MENU PLAY

This broadcast the mode as VCD2.0, DVD, MPEG4 etc. format disc valid, the disc of dissimilarity format, the menu interface also have dissimilarity.

TITLE PLAY

While broadcast DVD disc, can choice this broadcast a way

SELECTED PLAY

Press the remote control up of numeral key,can be direct selection to want to broadcast Of valid song.VCD disc when the PBC appearance broadcast, not Ability selected songs,can then can carry on seledted songs under the PBC menu.Not Together the disc selected songs effect of the format has a dissimilarity. For example want to chooseThe 5th or 23.

1, direct press numeral keyŸ5Ÿor pressŸ10+Ÿkey two,At this time television top the manifestation

REPEATED PLAY

In broadcasting appearance, pressing the remote controlŸrepeatŸkey, re-usable Broadcast the song that you want, the disc of dissimilarity format, repeated way Have a dissimilarity,. (the VCD disc be invalid when the menu broadcast appearance).

SLOW PLAY

In broadcasting appearance, pressing the remote controlŸSLOWŸkey, then get in to be Front of the speed broadcast, instauration arrive normal broadcast direct pressŸPLAYŸ Key then, or circulation press this key to arrive ŸOFFŸ appearance.Note:This mold When type broadcast have no audio frequency output.

VOLUME CONTROL

either directness press remote manipulator upperŸvolume+Ÿ , Ÿvolume- Ÿ or directness radial facing board last volume control knob came regulate.

PLAY MP3 DISH PIECE

it was singleness file type`dish piece then ingress first one list and play be one`s turn list subaltern first head song (cursor settle on 01 position), push-in inferior to bond selection menu Left Side list menu mesne either list, made choice of aback conbine pressŸENTER Ÿkey, machine then begin order play be one`s turn list mesne track,

here you what the hell press number key direct, selection that embed mp3 dish piece aback,video disc engine should automatic scan deposit mp3` severalty list,search done with aback, automatism precedence ingress mp3`first one list(toward file admixture lay up dish piece.

either track made choice of aback combine pressŸENTERŸkey, The unit then launch play be one`s turn track, here you what the hell press number key direct selection upon among push-in inferior to bond selection menu right list.

either in the coursee of track play,press ŸPREVŸorŸNEXTŸkey, could select play back piece or next track for.

Put out inferior to bond at image file compartment remove select, pitch on aback pressŸPLAYŸ key then begin to play by nowaday picture.

put out inferior to bond at image file compartment remove select, pitch on aback pressŸENTERŸ key namely appreciably saw be one`s turn picture, here picture get off to quietus,pressŸZOOMŸ key could magnify be one`s turn picture,press direction key could picture to different heading remove up for it.

at picture in a state of still hour, directness press direction key, could spin piece round.

either at picture in a state of still hour, press ŸPREVŸkey orŸNEXTŸkey could up or down turn over saw picture.

PressŸbroadcastŸkey beginning in proper order broadcast a picture

Enter the right side document menu after button up under to key, hold the picture contents that the left side of the act displays that document,can also browse with this mode.

PLAY MP3-JPEG DISH PIECE

While broadcasting with the disc of the mixture catalog,if Be broadcasting MP3 dotses, think browsing a picture can press the direction key to move to cursor a drawing mark of browse the picture up,clickŸENTERŸthe key enter the JPEG picture to browse a satus.

The method and function that the picture

Ÿ20+Ÿ,then again press few character key Ÿ3Ÿthen.

2,direct press numeral keyŸ5Ÿor continuous press Ÿ2 and 3Ÿnumeral key then.

WHILE CHOOSE PLAY

the remote control upŸGOTOŸkey,use direction key again and numeral key namely Can the completion choose function, end press ŸENTERŸthe key take effect, be Importation invalid time, would not take effect

UnderŸREPEATŸkey, could select: REP 1 (CHAPTER) ©REP DIR (TITLE)©REP ALL.

select respond repeat mode, then proceed homologous circulation play mode for it.

in the course of track play, pressŸPAUSEŸ key, approve pause play, anew press ŸPLAYŸkey then get play breath.

in the course of track play, pressŸSTOPŸ key, then ingressŸquasi ceaseŸsate, pressŸPLAYŸkey then again begin play by currently cease department round.

JPEG DISC PLAYBACK

the first one catalogic first frame picture department of the embed jpeg dish piece aback, video disc engine should automatic scan packing combine settle on run down.
browse with broadcast a JPEG disc homology.

USB PLAY

the file hour, play mode be like dish piece of
the while U tray suffer none but deposit a type of.

the file , should with direction key should
cursor move on to homologous typal icon down, pressŸENTERŸkey namely ingress be one`s turn typal file menu, then pitch on you want play`file pressŸPLAYŸorŸENTER keyŸ
namely approve of the the instant U inventory has fifferent kinds of trellised file,basic body search done with aback should first play music formatted file, as require play extended formatting.

Note:Such as need to broadcast the document in the U dish,please inside ,machine of the disc take out again close disc gateway then.

Before service, please nspects the question below

Main technical parameter

utput connection

Note:DESignandspecification parameterturnexcuse me not until further notice, wholeness in kindfinal.

Note: Particular specifications are subjected to change without prior notice.